

KODAK 605 Photo Printer Firmware Download Instructions

NOTE:

Do not unplug the USB cable or push any keys on the keyboard during the firmware download.

1. The target printer must be attached to the PC and in the "Ready" mode.
2. There can only be 1 605 printer attached to the PC when downloading firmware.
3. To begin firmware download, double click on Download.bat
4. The DOS window will show the files used to upgrade the firmware. There are 4 files:
 - USB
 - MAIN
 - DSP
 - TABLE
5. It will then show that 1 printer was detected on the USB bus.
6. Once the printer is detected, it will begin downloading and writing the 4 files to the printer one at a time.

NOTE:

During the MAIN download, and DSP Download you will see a 45 second countdown timer. When the timer reaches 0 the printer will reinitialize automatically.

7. After all 4 files have been written to the printer, the DOS Window will display "Completed Firmware Upgrade", and it will display all 4 files and associated versions.
8. The DOS Window will display "Press any key to continue...." Hitting any key will close the DOS window.

The new firmware is installed.

To verify the firmware version:

1. With the printer in the "Ready" mode, press the "Menu" button 6 times until you see "Main Firm=". The Main firmware version will be displayed.
2. Press the "Menu" button 1 more time and you should see "DSP Firm=". The DSP firmware version will be displayed.
3. Press "Clear" 1 time to return to ready.

Инструкция по прошивке микропрограммного обеспечения принтера KODAK 605 Photo Printer

Примечание: Не отключайте USB-кабель и не нажимайте клавиши на клавиатуре во время прошивки.

1. Целевой принтер должен быть подключен к компьютеру и должен быть в состоянии готовности ("Ready" на индикаторе).
2. Может быть только 1 принтер 605, подключенный к компьютеру при загрузке микропрограммного обеспечения.
3. Дважды кликните на Download.bat чтобы начать прошивку.
4. В окне будут показаны файлы, используемые для обновления прошивки. Есть 4 файла:

- USB
- MAIN
- DSP
- TABLE

5. Далее будет показано, что 1 принтер был обнаружен на шине USB.
6. После того как принтер будет обнаружен, он начнет загрузку и запись 4 файлов в принтер по одному за раз.

Примечание: Во время загрузки файлов MAIN и DSP вы увидите 45-секундный таймер обратного отсчета. Когда таймер достигнет 0, принтер автоматически будет переинициализирован.

7. После того, как все 4 файла будут написаны в принтер, в окне появится сообщение "Completed Firmware Upgrade" («Завершено обновление прошивки»), и будут отображаться все 4 файла и связанных с ними версии.
8. В окне появится сообщение "Press any key to continue...." («Нажмите любую клавишу для продолжения»), нажатие любой клавиши закроет окно.
Новая прошивка установлена.

Чтобы проверить версию прошивки:

1. На принтере в "Ready" режиме нажмите кнопку "Menu" в 6 раз, пока не появится "Main Firm=". Будет отображаться версия главной прошивки.
 2. Нажмите кнопку "Menu" еще 1 раз, и вы увидите "DSP Firm=". Будет отображаться версия прошивки DSP.
- Нажмите кнопку "Clear" 1 раз, чтобы вернуться в состояние готовности.